

EPC BARCODE: RALJU

DIP-switches 1-8 and 1-2 activate the respective LEDs. If monitoring a Test Point with Oscilloscope turn LEDs OFF to avoid signal distortion due to the LED acting as rectifier.



Test Points 1-10 that can be probed. From top to bottom



DIP-switches 3 to 8 are not used

DIP-switches 5 to 8 are not used



Use a flat cable to connect to front panel of:
VS State Machine
VS Regulation
VS Dig Interlock

Use DIP-switches 1-4 to select signals to Test Points 1-10

